

Wireless HDMI - WHD200 Quick Installation Guide

1

WHD200 Receiver

WHD200 Transmitter

HDMI Cable x 2

IR Repeater Cable

DC Power Adapter

USB Power Adapter

Quick Start guide

Anchors x 2, Screws x 2

Remote

2

WHD200 Transmitter

HDMI 1

HDMI 2

HDMI OUT

1st HD TV

Satellite Box

Games Console

3D Blu-ray

3

WHD200 Receiver

DC IN

HDMI OUT

2nd HD TV

HD Projector

4

WHD200 Receiver

DC IN

HDMI OUT

10-20 s

WHD200 Transmitter

HDMI 1

HDMI 2

HDMI OUT

Touchboards

205 Westwood Ave, Long Branch, NJ 07740
Phone: 866-94 BOARDS (26273) / (732)-222-1511
Fax: (732)-222-7088 | E-mail: sales@touchboards.com